

EAGLE LAKE ESTATES HOMEOWNERS ASSOCIATION
Architectural Control Committee
P.O. Box 07482
Fort Myers, FL 33919

GENERATOR & FUEL TANK GUIDELINE
for
Permanently Installed Generators & Permanently Installed Fuel Tanks

Location:

- Generator to be placed on small concrete slab adjacent to side or rear of home.
- Fuel Tank can be placed on a concrete slab like the generator or in the ground.
- With a minimum of five (5) feet from the property line*.
- Not to encroach on rear easement of the property**.

Conditions:

- Generator & above ground fuel tank must be concealed either with a vegetative hedge or a small fence. This is to establish/form an opaque barrier.
- Supply proof that the fuel tank was installed by a properly licensed/certified contractor.
- Architectural Committee members will make a final inspection upon completion.

Concealment:

- A vegetative hedge can be planted around the concrete slabs, with plants measuring 4' in height and planted 2' on center.
- **OR**
- A small fence can be built around the concrete slabs - as per the "Small Fence Guidelines". A gate is permitted.

* As per Article X, Section 2a, of the Declaration

** As per our Plat Map